

# RJ45 to DB25 Female/Male Crossover Cable

This cable will allow you to connect from the CM32 serial ports to console ports, terminals, printers and any other DTE RS232 device.

The wiring diagram is shown in Table 1.

**Table 1: EIA-232 RJ45 to DB-25**

From Port RJ45	Signal		Signal	To Port DB-25F/M
3	TxD	————	RxD	3
6	RxD	————	TxD	2
4	GND	————	GND	7
2	DTR		DSR	6
			DCD	8
8	DSR		DTR	20
7	DCD			
1	RTS	————	CTS	5
5	CTS	————	RTS	4

